



OPERATING INSTRUCTIONS

For lawn installation:

Secure the Mower Tilt to lawn with the spiraled lawn stake (included).

Slide lawn mower handle under curved end of Mower Tilt bracket and secure in place with attached quick-release pin.



For floor or wall installation:

Secure the Mower Tilt flush to the floor or wall stud using two 1/4" screws.

Slide lawn mower handle under curved end of Mower Tilt bracket and secure in place with attached quick-release pin.



SAFETY RULES



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

Read and understand all safety rules and operating instructions before using this product.

Follow all safety rules and operating instructions provided by your lawn mower's manufacturer when using this product.

Never allow children or untrained persons to use this product.

Do not capture engine safety handle while securing lawn mower handle with Mower Tilt.

Never use Mower Tilt while mower is running or engaged.

Always disconnect engine spark plug before using Mower Tilt.

Always wear protective gloves when servicing lawn mower blade.

Always secure handle with pin.

Always use on a level surface.

WARRANTY

If this product fails due to a defect in material or workmanship within ONE YEAR from the date of purchase, we will at our option repair or replace it free of charge.

This warranty does not cover:

- Repairs necessary because of operator abuse or negligence.
- Equipment used for commercial or rental purposes.
- Paint that is worn or faded due to normal use or exposure.

To arrange for product repair call 1.800.652.2321, or return this product to place of purchase for replacement.

This warranty gives you specific legal rights, and you may also have other rights which may vary from state to state. This warranty applies only while this product is in use in the United States.



Item # MT2000