



4T 18" X 24" PUSH-PULL STEEL LAWN ROLLER



READ AND FOLLOW ALL SAFETY RULES AND OPERATING INSTRUCTIONS BEFORE USING THIS EQUIPMENT

Safety Rules



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

Read and understand all safety rules and operating instructions before using this tractor attachment.

Follow all safety rules and operating instructions provided by your tractor's manufacturer when using attachment.

Never allow children or untrained persons to operate vehicle or attachment.

Do not carry passenger on vehicle or attachment.

Avoid sudden turns or maneuvers.

Do not remove warning decals from product.

Do not tow attachment on public roadways.

Check product for worn, loose or damaged parts before each use. If any damage is present, repair the product before using.

Check product for loose or missing fasteners before each use. Tighten or replace fasteners as needed before using.

Warranty

IF YOU ARE MISSING PARTS DO NOT RETURN TO STORE Email cs@ohiosteel.com or call 1-800-652-2321, ext. 212



Before you call, please email our customer service team at cs@ohiosteel.com with the following:

- A description of the issue you are having
- 2. Photos of the issue that include an overall view and detailed view from multiple angles
- 3. If applicable, a short video showing the issue

Replacement Parts:

You can place your parts order online at ohiosteel.com/partsstore

- You can also reach our Customer Service Department at 1-800-652-2321, ext. 212
- If you are ordering replacement part(s) for your product, please note that some parts are only available as a repair kit.

If this product fails due to a defect in material or workmanship within THREE YEARS from the date of purchase, we will at our option, only with receipt of purchase, repair or replace it free of charge. This warranty excludes the bushings and drainplug, which are expendable and become worn during normal use.


This warranty does not cover:

- Repairs necessary because of operator abuse or negligence.
- Equipment used for commercial or rental purposes.
- Paint that is worn or faded due to normal use or exposure.

To arrange for product repair visit **ohiosteel.com/customer-support** and fill out the warranty repair form. You can also call 1-800-652-2321, ext. 212 to speak to our Customer Service Team

This warranty gives you specific legal rights, and you may also have other rights which may vary from state to state. This warranty applies only while this product is in use in the United States.

Carton Contents




TOOLS REQUIRED FOR ASSEMBLY

• 1/2" Wrench or Socket


Pliers

Assembly Instructions


Attach Hub Assembly (2) to Hitch Side Bar (1) using 1" Hex Bolt (7) and Keps Nut (8). Note that open side of Hub Assembly (2) should face away from Hitch Side Bar (1).



Slide side bar assembly over axle stubs of Roller Drum (3). Slide 1" Washer (9) over axle stub and install cotter pin (10) into hole of axle stub. Secure by spreading legs of cotter pin (10).




Install Hitch Tube (4) onto side bar assemblies. Insert 2-3/4" Hex Bolt (11) through side bar assemblies and Hitch Tube (4). Install Keps Nuts (8) and tighten.




Assembly Instructions


4 Install Tube Plug (12) into Welded Clevis Handle (5).



Install Clevis Bar (6) and Welded Clevis Handle (5) onto Hitch Tube using 2-3/4" Hex Bolt (11) and Keps Nut (8). Roller is now in manual rolling mode.



6 Install Hitch Pin (13) and Cotter Pin (14) for towing mode.




Operating Instructions


Before Using Lawn Roller:

Read all Safety Rules found on page 1.

Though most rollers are filled with water, we recommend adding Ethylene Glycol Anti-Freeze with the water. This will protect the tank from damage during cold weather. It is also recommended that the anti-freeze used, contain a rust inhibitor to protect the inside of the tank against rust. If the roller is filled with water only, it must be drained whenever the temperature drops below 32 degrees F. (0 degrees C). The roller weighs approximately 920 pounds when filled. Safe disposal of the antifreeze is recommended. Please follow the Anti-Freeze manufacturers warnings and disposal methods.



Repair Parts



ITEM	PART NO	DESCRIPTION	QTY
1	404373-B2	BAR, SIDE, 1824 (BLACK)	2
2	6000570-B2	HUB, BUSHING, ROLLER (BLACK) (INCLUDES BUSHING)	2
3	504004-B2	DRUM, ROLLER, 1824 (BLACK)	1
4	404382-B2	TUBE, HITCH, 4T (BLACK)	1
5	6000831-B2	CLEVIS, HANDLE, 4T (BLACK) (INCLUDES PLUGS)	1
6	404391-B2	CLEVIS, HITCH, ROLLER (BLACK)	1
7		Hex Bolt, 5/16-18 x 1	4
8		Nut, Keps, 5/16-18	8
9	KIT - 6000596	WASHER, 1" SAE FLAT (ZINC)	2
10	0000370	COTTER PIN, 3/16 x 1 1/2 (ZINC)	2
11		HEX BOLT, 5/16-18 x 2.750 (ZINC)	4
12	6000597	PLUG, TUBE, 1" SQ	2
13	KIT	PIN, HITCH, 1/2" X 3" (ZINC)	1
14	6000770	COTTER HAIRPIN, 3/32" X 2-5/16" (ZINC)	1
15	50401	PLUG, DRAIN, ROLLER	1





Proudly designed and tested in Columbus, Ohio.

Manufactured in the U.S.A. from domestic and imported components.



MODEL #4T

2575 Ferris Road Columbus, OH 43224 (800) 652-2321

www.0HIOSTEEL.com (800) 652-2321